

## PIST-OM-ECO1.6-79.00XS Installation Information

We didn't want to compromise the strength of the piston by moving the skirt brace or machining part of it away, however on some occasions the oil squirter will foul our piston, so we recommend that the oil squirter position must be checked and re-align it if necessary.



The photo above shows how the oil squirter should be positioned, with it clearing the piston and aimed toward the middle of the piston.

### **THE OIL SQUIRTER WILL BEND EASILY – TREAT CAREFULLY**

It requires very little force to re-align the oil squirter, simply use a lever bar or long screwdriver between the mid-section of the squirter and rest against a suitable point on the block, apply a small amount of force until the squirter is aimed correctly.

***SBD/OMEGA piston PIST-OM-ECO1.6-79.00XS can only be used with our  
SBD/Saenz con-rods ROD-FD-ECO1.6-01S***

***Please be aware that Technical Support involving our Technicians is chargeable***